

FIG. 1




FIG 2



802/902





FIG. 7



Strain gages are mounted  
2 on each side of the  
shaft (4 total, full-  
bridge configuration)  
and then soldered onto  
solder tabs. Wires run  
down the center of the  
shaft to the end, where  
they are wired to a  
connector.



FIG. 10






FIG. 11





60 Hz passive filter




FIG. 12




FIG. 13




FIG. 14